



Using the Floodlight

1. Propane gas is highly flammable and must always be used with great care. Cylinders must not be stored in occupied domestic premises.
2. This floodlight is designed to provide general illumination in remote outdoor locations, on site, and in other well ventilated locations.
3. The floodlight must not be used where there is a fire risk from combustible materials, or flammable liquids and gases. Make sure there is no paper or other light, flammable materials that could be carried towards the floodlight by air flow.
4. Heated air and direct radiant heat from the floodlight can damage nearby objects as well as presenting a fire risk. Make sure that there are no objects near enough to the floodlight to get hot.
5. Plan the use of the floodlight so that it can always be used safely. It should not be left unattended if there is any risk of fire or burns to persons.
6. This floodlight must not be lit, moved, or adjusted, and the gas cylinder must not be changed, by minors, or by anyone under the influence of drugs or alcohol.
7. This floodlight is designed for operation by an able bodied adult. Anyone with either a temporary or permanent disability must seek expert advice before using it.

Please keep this leaflet safely as it may be required for future reference



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

1. If it is suspected that the cylinder connection is not gas tight, the floodlight should not be lit. Check that the valve handwheel is turned fully clockwise to the OFF position. Contact the hire company immediately.
2. If the floodlight does not work properly, attempts should not be made to repair or adjust it. Contact the hire company.
3. Make sure that there are no naked flames nearby, and that the area is cool down.
4. With the flame out, allow the light to immediately.
5. If the flame does not go out completely, if the flame has gone out wait until the flame has gone out completely.
6. Off position.
7. The floodlight should be turned off by turning the handwheel on the cylinder valve fully clockwise to the OFF position.
8. The floodlight should never be moved when it is lit.
9. Operators must make sure that they understand all of the controls.
10. Before the floodlight is lit it must be known how to turn it off.
11. Check the floodlight matches the connector on the gas regulator/valve. Check that the gas regulator/valve is used. Contact the hire company if anything is found damaged, the floodlight should not be used.
12. Check the floodlight, including the gas hose, clamp or stand, and connections should not be forced or improvised.
13. For stand lights, and lights fixed directly to gas cylinders a location should be chosen where they are going to be safe from vehicles, people, water, rain, strong gusts of wind, and other hazards which may damage them or knock them over.
14. Cloths or other materials must not be placed on or directly in front of the floodlight.



Before Starting Work...

Floodlight

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read this entire leaflet BEFORE using the Floodlight

1. Propane gas is highly flammable and must always be used with great care. Cylinders must not be stored in occupied domestic premises.
2. This floodlight is designed to provide general illumination in remote outdoor locations, on site, and in other well ventilated locations.
3. The floodlight must not be used where there is a fire risk from combustible materials, or flammable liquids and gases. Make sure there is no paper or other light, flammable materials that could be carried towards the floodlight by air flow.
4. Heated air and direct radiant heat from the floodlight can damage nearby objects as well as presenting a fire risk. Make sure that there are no objects near enough to the floodlight to get hot.
5. Plan the use of the floodlight so that it can always be used safely. It should not be left unattended if there is any risk of fire or burns to persons.
6. This floodlight must not be lit, moved, or adjusted, and the gas cylinder must not be changed, by minors, or by anyone under the influence of drugs or alcohol.
7. This floodlight is designed for operation by an able bodied adult. Anyone with either a temporary or permanent disability must seek expert advice before using it.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE



1. Keep gas cylinders upright at all times – whether in use, in store or being moved.
2. Propane gas cylinders should not be stored inside a building, even when they appear to be empty.
3. If a gas leak is suspected, the floodlight must be turned off using the control tap. Any naked lights and other sources of ignition must be put out. The area must be ventilated by opening doors and windows.
4. Never look for a leak with a naked flame – this is always extremely dangerous. Use soapy water.
5. If the cylinder is leaking, call the fire brigade and evacuate the area.
6. No attempts should be made to repair suspected leaks. Contact the hire company immediately.
7. In some conditions, frost may form on a gas cylinder that is in use. This indicates that the cylinder is not big enough to provide the flow of gas being used. Contact the hire company.
8. The cylinder must not be warmed to remove the frost. Care must be taken when handling a frosty cylinder as the cold can cause frost burns.
9. Handle cylinders carefully when moving them. They must not be dropped off vehicles – assistance must be sought to lower them safely.
10. Unused and empty cylinders must be kept away heat at all times.
11. Do not use this floodlight where WORK AREA

BEFORE USING THE FLOODLIGHT

1. Check the floodlight, including the gas hose, clamp or stand, and connections should not be forced or improvised.
2. For stand lights, and lights fixed directly to gas cylinders a location should be chosen where they are going to be safe from vehicles, people, water, rain, strong gusts of wind, and other hazards which may damage them or knock them over.
3. Cloths or other materials must not be placed on or directly in front of the floodlight.
4. Check the floodlight matches the connector on the gas regulator/valve. Check that the gas regulator/valve is used. Contact the hire company if anything is found damaged, the floodlight should not be used.
5. Before the floodlight is lit it must be known how to turn it off.
6. Make sure there are no papers or other light materials that could be carried towards the floodlight by air movement.
7. In areas where members of the public are allowed, barriers may be needed around lighting stands to keep people away from the heat, and light.
8. The floodlight should never be moved when it is lit.
9. Operators must make sure that they understand all of the controls.
10. Before the floodlight is lit it must be known how to turn it off.
11. Check the floodlight matches the connector on the gas regulator/valve. Check that the gas regulator/valve is used. Contact the hire company if anything is found damaged, the floodlight should not be used.
12. Check the floodlight, including the gas hose, clamp or stand, and connections should not be forced or improvised.
13. For stand lights, and lights fixed directly to gas cylinders a location should be chosen where they are going to be safe from vehicles, people, water, rain, strong gusts of wind, and other hazards which may damage them or knock them over.
14. Cloths or other materials must not be placed on or directly in front of the floodlight.

LPG FLOODLIGHT