

Using the Disc Sander

1. Wear your protective equipment including goggles and dust mask.
2. Use the sander with both hands. Use the side handle.
3. Make sure the sander is running at full speed before lowering it onto the surface.
4. Keep the sanding disc at a shallow angle to the surface of the work.
5. Apply only moderate pressure to the work surface. Do not press hard, you will overload the machine and may cause grooves in the workpiece.
6. Lift the sanding disc clear of the work before switching off.
7. Switch off and remove the plug before making adjustments or changing the sanding disc.
8. The disc will continue to rotate for a few seconds after you switch off. Wait for it to stop completely before you put the disc sander down.
9. Watch out for signs that vibrations may be affecting your hands. If your fingers start to tingle or feel numb, take a short break from using the disc sander. Exercise your fingers to encourage blood circulation.
10. Make sure that the machine ventilation slots do not become blocked with dust and debris.
11. Keep the cable clear from your sanding disc and any sharp edges on your work.
12. If you think the cable may be cut or damaged in any way, switch off and unplug at the mains before inspecting it. If the cable attached to the machine is damaged, stop using the machine. Contact the hire company. If an extension cable has been damaged, do not use it again.
13. Take care not to accidentally pull the plug from the socket.
14. Switch off and unplug before leaving the machine unattended.
15. If your equipment does not work properly, do not attempt to repair it. Contact the hire company.

Please keep this leaflet safely as it may be required for future reference



Hae
HIRE ASSOCIATION EUROPE

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solihull B37 7YF

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Before Starting Work...


Useful Reference Points • www.hae.org.uk/businessguard

Disc Sander

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

**It is important to read all of this leaflet
BEFORE you use the Disc Sander**

1. Plan your work ahead to make sure that you will always be working safely.
 2. Electricity can be hazardous and must always be used with great care.
 3. The disc sander is designed to sand or polish wood or metal surfaces. It will also remove rust. You must use the appropriate sanding, wire brushing, or polishing attachment.
 4. The sanding disc rotates very fast and can cause injury or damage if the machine is not used in a careful and controlled way.
 5. If you have not used a disc sander before, familiarise yourself with the machine on some straightforward work before you start on the main task.
 6. You must have at least the following items of personal protective equipment: Goggles: EN166 or BS2092; Dust mask - a minimum of EN149 FFP3(s) protection; Ear muffs or plugs giving protection for levels up to 98 dB(A); Gloves; rcd if using a 230 volt (mains) supply.
 7. This machine must not be used by minors, or anybody under the influence of drugs or alcohol.
 8. This machine is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.
- 



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Hae HIRE ASSOCIATION EUROPE
2450 Regents Court
The Crescent
Birmingham Business Park
Solihiull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
Website: www.hae.org.uk

- WORK AREA**
1. Do not use this disc sander where there is a danger of explosion. It will ignite fumes from your petrol or gas cylinders.
 2. Make sure that the area is clear and safe and that no-one is near you or could distract you.
 3. Protect other people from the noise and dust. Warn others to keep away.
 4. Any work that is not part of a fixture should be securely clamped or held in a vice.
 5. If you are working on a car or other vehicle, check that there are no fuel pipes where you are working. You might accidentally cut into them.
 6. Check that there are no electric cables, or small bore central heating pipes, fastened to the surface where you are going to sand. They may be damaged by the end of the sanding disc.
- OPERATORS**
1. The following items of personal protective equipment (PPE) are the minimum that should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection.
 2. You must wear goggles (EN166 or BS2092) when you are working with this machine.
 3. This equipment is likely to cause noise levels of up to 98 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum.
 4. You will need to wear an appropriate dust mask (with a minimum of EN149 FFP3(s) protection) when you are sanding material that causes dust.
 5. Anybody that is working near to you will also need to wear appropriate personal protective equipment.

DISC SANDER

1. Check your machine, cable, plugs and guards. If anything is found damaged,

SANDING DISCS

7. "I don't think that an additive wheel is the answer."



1. Use a residual current device ("r.c.d.") plugged into the 230V socket. Plug your machine into the r.c.d. This will help to protect you against electric shock if the cable or machine gets damaged.
2. Use the "TEST" button to check that the r.c.d. is working each time you use it. Reset the r.c.d. according to the instructions supplied with it.
3. If you need an extension cable, follow any special instructions given to you by the hire company. If not given you any special instructions, you should only use a suitably rated heavy duty, not longer than 50 metres (160 feet). Plug directly into the r.c.d.
4. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.
5. Make sure that any extension cable connections are dry and safe.