



Using the Floor Cleaner / Polisher

1. Protective equipment including non-slip shoes must be worn.
2. Many floor cleaners have two control levers which need to be held in to operate the machine. Both hands should be kept on the handlebars at all times – the machine cannot be controlled one-handed.
3. By gently raising and lowering the control arm the cleaner can be controlled so that it sweeps from side to side in an arc. Move forwards steadily to achieve proper coverage of the floor.
4. The control tap to release cleaning solution can be operated without releasing the handlebars.
5. Keep a check on the position of the cable so that it does not get run over, stretched, or the plug is not accidentally pulled from the socket.
6. Keep the cable clear of any sharp edges in the work area.
7. If it appears that the cable may be cut or damaged in any way, switch off and unplug at the mains before inspecting it. If the cable attached to the floor cleaner is damaged, stop using the equipment. Contact the hire company. If an extension cable has been damaged, do not use it again.
8. Switch off and unplug from the socket before leaving the machine unattended.
9. When the work has been finished, empty any remaining cleaning solution and partly refill with clean water. Operate the machine in a safe place to flush the cleaning solution out of the equipment.
10. Keep everyone, especially young children and the infirm, off the cleaned floor until it is dry. They could fall on the slippery surface.
11. If the equipment does not work properly do not attempt to repair it. Contact the hire company.

Please keep this leaflet safely as it may be required for future reference



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

1. The extension cable must be laid out carefully avoiding any liquids, sharp edges, doorways or windows where it might be trapped, and places where it may be run over by vehicles. It should be unrolled fully or it will overheat and could catch fire.
2. Make sure that any extension cable connections are dry and safe.
3. The cable should be plugged directly into the socket. Do not use a multi-way adapter.
4. If an extension cable is required, follow any special instructions given by the hire company. If the hire company has not given any special instructions, only a suitably rated heavy duty extension cable should be used, not longer than 50 metres (160 feet). It should be plugged directly into the socket.
5. If an extension cable is required, follow any special instructions given by the hire company. If the hire company has not given any special instructions, only a suitably rated heavy duty extension cable should be used, not longer than 50 metres (160 feet). It should be plugged directly into the socket.



230 VOLT MACHINES
(SQUARE PIN OR BLUE PLUG)

1. A residual current device (r.c.d.) should be used, plugged directly into the 230V socket. The cleaner should be plugged into the r.c.d. This will help protect against electric shocks if the cable or equipment gets damaged.
2. The "TEST" button should be used to check that the r.c.d. is working each time it is used. The r.c.d. should be reset according to the instructions supplied with it.
3. If an extension cable is required, follow any special instructions given by the hire company. If the hire company has not given any special instructions, only a suitably rated heavy duty extension cable should be used, not longer than 50 metres (160 feet). It should be plugged directly into the socket.
4. Make sure that any extension cable connections are dry and safe.



110 VOLT MACHINES (YELLOW PLUG)

1. If the portable transformer is being used, the transformer should be plugged directly into the 230V socket. 230V extension cables should not be used.
2. If an extension cable is required, follow any instructions given by the hire company. If the hire company has not given any special instructions, only a suitably rated heavy duty extension cable should be used, not longer than 50 metres (160 feet). The cable must only be used between the transformer and the cleaner.
3. If an extension cable is required, follow any special instructions given by the hire company. If the hire company has not given any special instructions, only a suitably rated heavy duty extension cable should be used, not longer than 50 metres (160 feet). The cable must only be used between the transformer and the cleaner.
4. Make sure that any extension cable connections are dry and safe.



Before Starting Work...

Floor Cleaner / Polisher

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read this entire leaflet BEFORE using the Floor Cleaner / Polisher

1. Electricity can be hazardous and must always be used with great care.
2. Electricity and water can make a hazardous combination. Care must be taken whenever water or other solutions are used to keep them away from plugs, sockets, switches and the electrical parts of the cleaner.
3. This floor cleaner is designed for cleaning, polishing and scrubbing hard surfaced floors. It may also be used to help clean some carpets, with the correct brushes fitted.
4. The action of this floor cleaner can cause injury or damage to property if the equipment is misused.
5. If the operator has not used a floor cleaner before, they should familiarize themselves with the equipment on a small area of the floor before starting on the main task.
6. A minimum of the following items of personal protective equipment must be worn: ear muffs or plugs giving protection for levels up to 86 dB(A); waterproof gloves; non-slip shoes; rcd if using a 230 volt (mains) supply.
7. This equipment must not be used by minors or by anyone under the influence of drugs or alcohol.
8. This floor cleaner is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE



1. Check the floor cleaner, cables, plugs and all other equipment. If anything is damaged, do not use it.
 2. This equipment is likely to cause noise levels up to 86 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum. If the cleaner is going to be used continuously, waterproof gloves should be worn if cleaning or other chemicals are to be used.
 3. Waterproof gloves should be worn if cleaning or other chemicals are to be used.
 4. Fill the solution tank with cold or warm water. Do not put very hot water into the tank.
 5. Read the instructions supplied with any cleaning chemicals which are to be used.
 6. Read the instructions supplied with any cleaning chemicals which are to be used.
 7. If the control arm is adjustable, set it to a comfortable height. Make sure that it is locked into position.
 8. A range of different brushes, pads and chemicals are available for different applications. These include stripping, scrubbing and polishing.
1. The following items of personal protective equipment (ppe) are the minimum that should be worn whenever the equipment is used. Particular jobs or environments may require a higher level of protection.
 2. This equipment is likely to cause noise levels up to 86 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum. If the cleaner is going to be used continuously, waterproof gloves should be worn if cleaning or other chemicals are to be used.
 3. Waterproof gloves should be worn if cleaning or other chemicals are to be used.
 4. Non-slip shoes should be worn.
 5. Anyone who is working nearby will also need to wear appropriate protective clothing.
1. Check the floor cleaner, cables, plugs and all other equipment. If anything is damaged, do not use it.
 2. This equipment is likely to cause noise levels up to 86 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum. If the cleaner is going to be used continuously, waterproof gloves should be worn if cleaning or other chemicals are to be used.
 3. Waterproof gloves should be worn if cleaning or other chemicals are to be used.
 4. Fill the solution tank with cold or warm water. Do not put very hot water into the tank.
 5. Read the instructions supplied with any cleaning chemicals which are to be used.
 6. Read the instructions supplied with any cleaning chemicals which are to be used.
 7. If the control arm is adjustable, set it to a comfortable height. Make sure that it is locked into position.
 8. A range of different brushes, pads and chemicals are available for different applications. These include stripping, scrubbing and polishing.

