



Errut Stone Splitter

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read this entire leaflet BEFORE using the Errut stone or slab splitter



1. This stone splitter generates enormous pressure between the blades, and can be hazardous if misused.
2. The Errut stone splitter is designed for cutting paving slabs, splitting natural stone, and for similar jobs.
3. The action of this stone splitter can cause injury or damage if not used in a careful and controlled way. It is very heavy, take care when moving it.
4. If you have not used this type of equipment before, familiarise yourself with how it works and the hazards it presents before you start work.
5. Plan your work and think ahead to make sure you will always be working safely.
6. You must have at least the following items of personal protective equipment: impact resistant goggles; safety boots; gloves.
7. This Errut stone splitter must not be used by minors, or by anyone under the influence of drugs or alcohol.
8. This stone splitter is designed for operation by an able bodied adult. Anyone with either a temporary or permanent disability must seek expert advice before using it.



Hae
HIRE ASSOCIATION EUROPE

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Soliuhull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Soliuhull B37 7YE

Hae
HIRE ASSOCIATION EUROPE

©Copyright Hire Association Europe April 2011

USING THE ERRUT STONE SPLITTER

1. Wear your protective equipment. Wear your gloves to position the material in the splitter.
 2. Keep other persons away, safe from the danger of flying chips.
 3. With the valve closed, pump the handle to force the upper blade down on to the material.
 4. The pressure release valve is at the base of the jack. Unscrew it one or two turns to release the hydraulic pressure to allow the upper blade to retract. Screw it finger tight to close the valve. Do not remove the pressure release valve completely.
 5. Do not attempt to relocate the block or slab being split while it is under pressure.
 6. Do not try to split more than one slab or block at a time.
 7. The material being split will fall off, either side of the splitter - keep your feet clear.
 8. Move the split material away, do not allow your workplace to become cluttered.
 9. Stop work if someone approaches you.
 10. If your equipment does not work properly, do not attempt to repair it. Contact the hire company.
- Please keep this leaflet safely as it may be required for future reference



Before Starting Work...

Useful Reference Points • www.hae.org.uk/businessguard

1. The following items of personal protective equipment (ppe) are the minimum that should be worn whenever you use this stone splitter: goggles when you are working with this machine.
2. You must wear safety boots.
3. Anyone who is working close by will also need to wear appropriate personal protective equipment.
4. There are several sizes of slab splitters and several models for splitting blocks and stone. If you need a different machine for the work you are doing, contact the hire company.
5. Check that the stone splitter is sited firmly and safely, on a solid level surface, near to your work area.
6. Make sure you understand how the equipment works - before you use the stone splitter you must be aware of the potential hazards present and what precautions to take.
7. The threaded section on the jack is used to adjust the gap between the splitter - contact the hire company.

OPERATORS

1. Make sure that the work area is clear and safe and that no-one is nearby or could cause distraction.
2. Protect other people from injury. Warn others to keep away, put barriers around your work area.

ERRUT STONE SPLITTER

2. Check the equipment. If anything is found damaged, do not use the stone splitter.