



Using the Dehumidifier

1. Ensure the unit is sited in a safe secure position before switching on.
2. Check the water level regularly and empty as necessary.
3. Keep cables clear of any sharp edges in the work area.
4. If the cable appears to be cut or damaged in any way, switch off and unplug at the mains before inspecting it. If the cable attached to the dehumidifier is damaged, stop using the equipment. Contact the hire company. If an extension cable has been damaged, do not use it again.
5. Do not restart the dehumidifier immediately after switching it off – this can be harmful to the equipment. Leave it for approx. 5 minutes before restarting.
6. Take care not to accidentally pull the plug from the socket.
7. Switch off and remove the plug from the socket before carefully moving the unit.
8. Switch off and remove the plug when not using the unit.
9. If the equipment does not work properly do not attempt to repair it. Contact the hire company.

Please keep this leaflet safely as it may be required for future reference

Dehumidifier

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read this entire leaflet BEFORE using the dehumidifier

1. Plan your work and think ahead to make sure you will always be working safely.
2. Electricity is dangerous and must always be used with great care.
3. Electricity and water make a very dangerous combination. Keep electrical equipment away from rain and water.
4. This dehumidifier is designed to help dry out new buildings and other buildings which have become temporarily damp.
5. The weight of this dehumidifier can cause injury or damage if the equipment is not moved in a careful and controlled way.
6. If you have not used a dehumidifier before, familiarise yourself with how it works before you set it up.
7. You should have at least the following items of protective equipment: rcd if using a 230 volt (mains) supply.
8. This equipment must not be used by minors, or by anyone under the influence of drugs or alcohol.
9. This dehumidifier is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE



1. Use a residual current device ("rcd") plugged directly into the 230v socket. Plug the equipment into the socket. Plug the equipment into the 230v socket. Plug the equipment into the 230v socket. Plug the equipment into the 230v socket.
2. Use the "TEST" button to check the rcd is working each time it is used. Reset the rcd according to the instructions supplied with it.
3. If an extension cable is required, follow any special instructions given by the Hire Company. If the hire company has not given any special instructions a suitably rated heavy duty extension cable not longer than 50 metres (160 feet) should be used. Plug the cable directly into the rcd.
4. Lay the cable out carefully avoiding liquids, sharp edges, doorways or windows where it may be trapped, and avoid places where vehicles might run over it. Unroll it fully or it will overheat and it may catch fire.
5. Ensure any extension cable connections are dry and safe.

1. If a portable transformer is being used, plug the transformer directly into the 230v socket. Do not use any 230v extension cables.
 2. If an extension cable is required, follow any special instructions given by the Hire Company. If the hire company has not given any special instructions a suitably rated heavy duty 110v extension cable, not longer than 50 metres (160 feet) should be used. An extension cable must only be used.
- 110 VOLT MACHINES (YELLOW PLUG)**
1. Do not restart the dehumidifier immediately after switching off – this can be harmful to the equipment. Leave for about 5 minutes before restarting.
 16. Check how the control switches work. Before switching on the dehumidifier ensure the stop switch can be located.
- EQUIPMENT**
- Your equipment will only operate on one 230v equipment will have either a normal square pin plug fitted or a blue industrial plug. Read the instructions below for your equipment.
 10. The drain outlet pipe should slope downward and must be placed in a permanent drain or sink, or fed to a closed container to prevent re-evaporation.
 11. If using a closed container like a plastic sorer top container, check and empty the water frequently to ensure it does not overflow.
 12. Some dehumidifiers have their own built in water container and water level gauge. ice will normally form on the condenser coil and should defrost itself regularly. If not to become injured when moving it about – it may be heavier than you think. Equipment designed to run directly from 230v mains will have either a normal square pin plug fitted or a blue industrial plug.
 14. Do not use any form of heat to remove the ice.



Before Starting Work...

1. Do not use this dehumidifier where there is a danger of explosion. It will ignite fumes from petrol or gas cylinders.
 2. Keep others including children and animals well away from the area.
 3. The outer doors and windows of the building being dried must be kept closed while the equipment is in use.
 4. To dry out a large building, locate a dehumidifier on each floor. If you only have one dehumidifier move it to different floors starting on the lowest floor. Keep upper doors shut until you move to that level.
 5. The dehumidifier works best if the temperature in the area is at least 60°F or 16°C.
 6. This dehumidifier can be left unattended once it has been set up safely.
- DEHUMIDIFIER**
1. Check the equipment: cables, plugs and connections or improve them.
 2. Check the plug on the equipment matches the supply. Do not try to force connections or improvise them.
 3. Equipment with a cylindrical yellow industrial plug fitted is designed to run off a special 110v supply. The hire company will provide a portable transformer if the equipment is to be powered from a normal mains 230v supply. If a portable transformer has been supplied, take care not to become injured when moving it. The ice forms into a solid block which will not melt until the ice has melted. If you have not used a dehumidifier before, familiarise yourself with how it works before you set it up.